

QUALITY
since 1948

PRESSURES PER AGRICULTURAL TYRES

Pressures are given in bars, loads given in kg. To obtain load per tyre you should weigh the tractor with the implement attached and raised, per drive axles, and divide per 2.



Peace of mind, every time

Pressures Per agricultural tyres KLEBER

High volume

KLEBER TOPKER

Pressures (bar) & Max.load (kg) per Tyre - Take into account the load and type of work when adjusting pressures									
SPEED in km/h	0,6	1,0	1,2	1,6	1,8	2,0	2,4	2,8	Capacity in litres of water 75% max
600/65R28 TL 154A8/154B									
30	1900	2480	2770	3350	3510	3675	3840	4000	405
40		2360	2625	3150	3300	3450	3600	3750	
600/70R28 TL 157A8/157B									
30	2060	2785	3150	3875	4030	4190	4345	4500	470
40		2575	2900	3550	3695	3840	3980	4125	
650/75R38 TL 169A8/169B									
30	2900	3860	4340	5300	5510	5725	5940	6150	709
40		3550	3990	4875	5105	5340	5570	5800	
650/85R38 TL 173A8/173B									
30	3250	4350	4900	6000	6225	6450	6675	6900	821
40		4000	4485	5450	5710	5975	6240	6500	

Low Profile 70

KLEBER FITKER

Pressures (bar) & Max.load (kg) per Tyre - Take into account the load and type of work when adjusting pressures									
SPEED in km/h	0,4	0,6	0,8	1,0	1,2	1,4	1,6	Capacity in litres of water 75% max	
320/70R24 TL 116A8/116B									
30	620	890	980	1070	1160	1250	1340	105	
40		830	915	1000	1080	1165	1250		
360/70R24 TL 122A8/122B									
30	750	1070	1180	1285	1395	1500	1610	136	
40		990	1090	1195	1295	1400	1500		
380/70R24 TL 125A8/125B									
30	820	1170	1290	1410	1530	1650	1770	160	
40		1090	1200	1315	1425	1540	1650		
420/70R24 TL 130A8/130B									
30	950	1350	1485	1620	1760	1895	2030	203	
40		1250	1380	1510	1640	1770	1900		
480/70R24 TL 138A8/138B									
30	1170	1680	1850	2020	2190	2360	2530	276	
40		1560	1720	1880	2040	2200	2360		
360/70R28 TL 125A8/125B									
30	820	1170	1290	1410	1530	1650	1770	153	
40		1090	1200	1315	1425	1540	1650		
380/70R28 TL 127A8/127B									
30	870	1250	1375	1500	1620	1745	1870	179	
40		1160	1280	1395	1515	1630	1750		
420/70R28 TL 133A8/133B									
30	1020	1470	1615	1760	1910	2055	2200	231	
40		1360	1500	1640	1780	1920	2060		
480/70R28 TL 140A8/140B									
30	1240	1780	1960	2140	2320	2500	2680	302	
40		1650	1820	1990	2160	2330	2500		
480/70R30 TL 141A8/141B									
30	1280	1830	2015	2200	2390	2575	2760	316	
40		1700	1875	2050	2230	2405	2580		
480/70R34 TL 143A8/143B									
30	1360	1940	2135	2330	2530	2725	2920	345	
40		1800	1985	2170	2360	2545	2730		
520/70R34 TL 148A8/148B									
30	1570	2240	2465	2690	2920	3145	3370	422	
40		2080	2295	2510	2720	2935	3150		
480/70R38 TL 145A8/145B									
30	1440	2060	2270	2475	2685	2890	3100	377	
40		1910	2110	2305	2505	2700	2900		
520/70R38 TL 150A8/150B									
30	1670	2380	2620	2860	3100	3340	3580	464	
40		2210	2440	2665	2895	3120	3350		
580/70R38 TL 155A8/155B									
30	1930	2760	3040	3315	3595	3870	4150	590	
40		2560	2825	3090	3350	3615	3880		
620/70R42 TL 160A8/160B									
30	2240	3180	3510	3835	4165	4490	4820	658	
40		2970	3275	3580	3890	4195	4500		

Low profile 65

KLEBER GRIPKER

Pressures (bar) & Max.load (kg) per Tyre - Take into account the load and type of work when adjusting pressures									
SPEED in km/h	0,6	0,8	1,0	1,2	1,4	1,6	Capacity in litres of water 75% max		
440/65R24 TL 128D									
30	1120	1340	1560	1780	1925	2070	178		
40		1285	1490	1700	1835	1970			
480/65R24 TL 133D									
30	1290	1530	1770	2010	2190	2370	218		
40		1455	1690	1920	2090	2260			
540/65R24 TL 140D									
30	1530	1835	2135	2440	2660	2880	287		
40		1745	2030	2320	2530	2740			
440/65R28 TL 131D									
30	110	1425	1665	1900	2070	2240	198		
40		1355	1580	1810	1975	2140			
480/65R28 TL 136D									
30	1370	1645	1915	2190	2385	2580	242		
40		1560	1820	2080	2265	2450			
540/65R28 TL 142D									
30	1645	1955	2270	2580	2815	3050	318		
40		1855	2150	2450	2675	2900			
540/65R30 TL 143D									
30	1690	2010	2330	2650	2890	3130	333		
40		1915	2220	2520	2750	2980			
540/65R34 TL 145D									
30	1805	2165	2520	2880	3110	3340	364		
40		2060	2400	2740	2960	3180			
600/65R34 TL 151D									
30	2130	2535	2935	3340	3655	3970	464		
40		2415	2800	3180	3480	3780			
540/65R38 TL 147D									
30	1910	2260	2610	2960	3250	3540	394		
40		2155	2490	2820	3095	3370			
600/65R38 TL 153D									
30	2250	2680	3110	3540	3870	4200	500		
40		2555	2960	3370	3685	4000			
650/65R38 TL 157D									
30	2520	3005	3485	3970	4355	4740	602		
40		2855	3320	3780	4150	4520			
650/65R42 TL 158D									
30	2650	3165	3685	4200	4545	4890	646		
40		3015	3510	4000	4325	4650			

Large

KLEBER SUPER 8L **

Pressures (bar) & Max.load (kg) per Tyre - Take into account the load and type of work when adjusting pressures									
SPEED in km/h	0,6	0,8	1,2	1,6	2,0	2,2	2,4	Capacity in litres of water 75% max	
260/70R16 TL 109A8/106B									
30	440	515	660	805	955	1025	1100	45	
40		410	480	615	755	890	960		
280/70R16 TL 112A8/109B									
30	490	570	725	885	1040	1120	1200	50	
40		460	535	680	825	975	1045		
280/70R18 TL 114A8/111B									
30	520	600	765	930	1095	1180	1260	52	
40		490	565	720	875	1025	1105		
280/70R20 TL 116A8/113B									
30	550	640	815	990	1165	1250	1340	57	
40		515	595	760	925	1085	1170		
300/70R20 TL 119A8/116B									
30	620	715	900	1085	1275	1365	1460	71	
40		580	665	840	1015	1185	1275		
320/70R20 TL 123A8/120B									
30	670	780	1000	1220	1440	1550	1660	79	
40		630	730	935	1140	1345	1450		
360/70R20 TL 129A8/126B									
30	800	930	1195	1455	1720	1850	1980	112	
40		750	870	1115	1360	1605	1730		
SPEED in km/h	0,6	0,8	1,0	1,2	1,4	1,6	Capacity in litres of water 75% max		
420/70R30 TL 134A8/131B									
30	1230	1440	1645	1855	2060	2270	229		
40		1150	1345	1540	1730	1925	2120		

CAUTION

Use the technical documentation and inflation tables which show the load/pressure figures for different operating speeds. These load/pressure tables correspond to the tyre deflection allowed by the manufacturer. If the pressure is incorrect, the tyre is either under or over inflated, which can cause:

- either unsatisfactory performance in the field (grip/load capacity) or unsatisfactory road holding leading to a loss of control;
- or damage (premature casing fatigue)
- or uneven wear that may reduce the life of the tyre.

Apart from correct initial inflation it is also recommended that the pressure be checked periodically and corrected if any air has been lost.

NOTA

We recommend replacing the rubber valve or the seals on the metal at each tyre replacement. The above details are subject to modification after publication (May 2012)



Peace of mind, every time

